

NOTES:

2) OPERATING TEMPERATURE: -40°C TO +80°C.

3) STANDARD PART IDENTIFICATION TO INCLUDE PART NUMBER, DATE CODE AND WARNING MESSAGE. WARNING MESSAGE.

4) GAS SPRING IS SUGGESTED TO BE MOUNTED SHAFT DOWN (ROD DOWN) FOR MAXIMUM PERFORMANCE. 5) END FITTINGS TO BE ORIENTED AS SHOWN ±5°.

6) GAS SPRINGS WILL BE SEALED IN CLEAR PLASTIC BAGS TO AVOID DAMAGE, DUST, OR OTHER FOREIGN OBJECTS.

7) GAS SPRING TO BE ASSEMBLED WITH END FITTINGS COMPLETELY FASTENED.